

SETUP

SLATE AX

CREATES WIFI

IPHONE & LAPTOP WILL AUTOMATICALLY
CONNECT TO THE WIFI



CH1



CH2



CH4



STUDIO/INTERVIEW

CH3



AMBIENT
COURT SOUND

WIFI



MAIN CAMERA
POWERBANK

WIFI



ALTERNATIV ANGLE
POWERBANK

WIFI




ALTERNATIV ANGLE
POWERBANK

WIFI



ALTERNATIV ANGLE
POWERBANK



— = NETWORK
— = XLR AUDIO

AUDIO SETUP
(MIXER TO
LAPTOP)

COMMENTATOR
CH 1 & CH 2

AMBIENT
COURT SOUND
CH 3

INTERVIEW/STUDIO
CH 4

USB TO LAPTOP
(POWER/AUDIO IN)

PHONE SPLITTER:
MALE TELE TO
PHONES
HEADSET IN TO
DOUBLE FEMALE
FOR RETURN
SOUND



SLATE AX

SLATE AX IS A ROUTER
THAT CREATES A WIFI


*IPHONE & LAPTOP WILL AUTOMATICALLY
CONNECT TO THE WIFI*



ETHERNET FROM
ARENA TO WAN IN
SLATE AX

POWER BY USB C
ALTERNATIV POWER SOURCE CAN
BE A POWERBANK IF NEEDED

STREAMCAST PRO



- CHANGE IP OR SRT PORT

COG WHEEL – CONNECTIONS – MANAGE CONNECTION – CHOOSE CONNECTION TO EDIT.
TO CHANGE PORT. CHANGE THE LAST 4 DIGIT IN THE IP ADDRESS.
IN THE SAME PAGE YOU CAN ALSO CHANGE THE LATENCY
REMEMBER TO SAVE IF NEEDED (DEPENDS ON THE APP VERSION)

- CHANGE BITRATE
COG WHEEL – VIDEO – BITRATE

- CHANGE FORMAT (H.264 – HEVC)
COG WHEEL – VIDEO - FORMAT

Gotke / Harding
Moreno / Yelnik

3 40
3 0


SAVE UP TO 40% ON HOTELS WORLDWIDE!

ROCKS LANE
Official Accommodation Partner of Rocks Lane

Cano
Water

YEW
SUPER NATURAL
SPARKLING WATER

MAIN CAMERA
POSITION. LEAVE SPACE
FOR THE VIRTUELL LED



**ALTERNATIV
LOW ANGLE**